



- ① REMOVE INSULATION TO SUIT BOOT
- ② RETROFIT PIPE BOOT-HIGH TEMP WHERE NEEDED
- ③ SEALANT
- ④ BUTYL TAPE ALL AROUND
- ⑤ STAINLESS STEEL BAND CLAMP
- ⑥ FASTEN ALL AROUND
- ⑦ TRIM HANGER IF NEEDED
- ⑧ PIPE OR CONDUIT PENETRATION

-
 LMPM "B" PIPE PENETRATION
 -
 NTS